



EE2028 Microcontroller Programming and Interfacing

Assignment 2

Friday_PM

Group 10

Huang Zhiwen (A0194530H)

Du Yutong (A0194545W)

Content

1. Introduction
2. Objectives
3. Flow chart
4. Detailed implementation
5. Enhancement
6. Problems encountered and solutions
7. Issue and suggestions
8. Conclusion


1. Introduction

In this project, we designed and implemented a novel monitoring system for medical purpose. Its main target group is COVID patients, especially early COVID patients. We shall call this system as COvid Patient Enhanced MONitoring, or COPEMON. COPEMON is established based on STM32 with those embedded sensors, and it is designed to have two different monitoring mode, including Healthy mode and Intensive Care mode. COPEMON will detect and report the patients' different physical situations according to the mode of the system. Healthy mode is mainly used for early COVID patients, COPEMON can monitor the temperature, and it also has falling warning function. If the patient's temperature is above normal or free fall of the patient is detected, LED on COPEMON will blink, and the warning message will be sent to the computer. Doctors will be warned to check the situation of the patient. If doctors decide to switch the system to Intensive Care mode to have a all-rounded monitor to a certain patient. Besides temperature and free fall detection, the COPEMON will also check the patient's body orientation, lung pressure and humidity, and body movement. COPEMON will send all these data to the computer every 10 seconds. Similarly, if any of the data is beyond the safety threshold, COPEMON will also send warning messages.

2. Objectives

- Switch between two different modes.
- Detect and gather all kinds of data through different sensors.
- Print all kinds of data on computer through UART in a certain frequency.
- Send warning messages if the situation of the patient is abnormal.

3. Flow chart



4. Detailed implementation

- Line 9-Line 29:

Include all library file used in the following code. Define all kinds of thresholds used below to determine the situation of the patient's body condition. Declare functions to configure UART and GPIO.

```

7  /* Includes ----- */
8  #include "main.h"
9  #include <math.h>
10 #include "../Drivers/BSP/STM32L475E-IOT01/stm32l475e_iot01_accelero.h"
11 #include "../Drivers/BSP/STM32L475E-IOT01/stm32l475e_iot01_tsensor.h"
12 #include "../Drivers/BSP/STM32L475E-IOT01/stm32l475e_iot01_gyro.h"
13 #include "../Drivers/BSP/STM32L475E-IOT01/stm32l475e_iot01_magneto.h"
14 #include "../Drivers/BSP/STM32L475E-IOT01/stm32l475e_iot01_psensor.h"
15 #include "../Drivers/BSP/STM32L475E-IOT01/stm32l475e_iot01_hsensor.h"
16 #include "stdio.h"
17 #include "stm32l4xx_it.h"
18 #include "string.h"
19 #define TEMP_THRESHOLD 37.4
20 #define GYRO_THRESHOLD 100
21 #define HUMID_THRESHOLD 70
22 #define PRESSURE_THRESHOLD 1050
23 //extern void initialise_monitor_handles(void); // for semi-hosting support (printf)
24 static void MX_GPIO_Init(void);
25 static void UART1_Init(void);
26 void HAL_GPIO_EXTI_Callback(uint16_t GPIO_Pin);
27 HAL_HandleTypeDef huart1;
28 UART_HandleTypeDef huart1;
29 int buttonpress=0,fall_warning=0;

```

- Line 30- Line 57:

Initial all kinds of variables used below. Initial peripherals.

mode=0: Healthy mode

mode=1: Intensive Care mode

mode=3: Password page

mode=4: Welcome page (There is no mode=2)

lying_time: used as clock for magnet_warning

sample_time: used as clock for reading data

press_time: used to determine the interval of two pushes

blink_time: used as clock for LED blinking

current_time: used as clock for other warnings

press: how many times you press the button

temp_warning, gyro_warning, magnet_warning, humid_warning, pressure_warning: flags for warnings

blink: flag for LED blinking

```

30 int main(void)
31 {
32     int mode=4; //0 for healthy mode and 1 for intensive care mode
33     int seconds_count = 0,enter1=0,enter2=0;
34     int current_time=0,lying_time=0,sample_time=0,press_time=0,blink_time=0,press=0; //press: how many times you press the button
35     int temp_warning=0,gyro_warning=0,magnet_warning=0,humid_warning=0,pressure_warning=0,firstdetect=0;
36
37     char line_print[64];
38     char buffer[64];
39
40     HAL_Init();
41     UART1_Init();
42
43     /* Peripheral initializations using BSP functions */
44     BSP_ACCELERO_Init();
45     BSP_TSENSOR_Init();
46     BSP_GYRO_Init();
47     BSP_MAGNETO_Init();
48     BSP_HSENSOR_Init();
49     BSP_PSENSOR_Init();
50
51     MX_GPIO_Init();
52     HAL_NVIC_EnableIRQ(EXTI15_10_IRQn);
53     SENSOR_IO_Write(0x04,0x58,0x00); //enable free fall interrupt
54     SENSOR_IO_Write(0x04,0x5E,0x00); //configure in
55     int blink=0;
56     char password[]="0000",wrong[]="Password incorrect.(Enter EXIT to quit)\n\r",exitmode1[]="EXIT",exitmode2[]="exit",exitmode3[]="Exit";
57     char exitmode[]="Exit Successfully\n\r";

```

- Line 58- Line 108:

Initial all variables and arrays used to record data from sensors. Record and process raw data from sensors. Record the patient's initial body orientation (maget_data).

```

59 {
60     int len=0;
61     char data;
62     char fall[]="Falling is detected\n\r";
63     char breath[]="Check patient's breath!\n\r";
64     char healthymode[]="Entering Healthy Mode\n\r";
65     char intensivemode[]="Entering Intensive Care Mode\n\r";
66     float accel_data[3];
67     float gyro_data[3];
68     float maget_data[3];
69     float gyro_magnitude;
70     float original_orientation[3];
71     char fever[]="Fever is detected\n\r";
72     char pain[]="Pain is detected\n\r";
73     char orientation[]="Check patient's abnormal orientation!\n\r";
74     float temp_data, humidity_data, pressure_data;
75     int16_t accel_data_i16[3] = { 0 }; // array to store the x, y and z readings.
76     int16_t maget_data_i16[3]={0};
77     if(HAL_GetTick()-sample_time>1000)
78     {
79         BSP_ACCELERO_AccGetXYZ(accel_data_i16); // read accelerometer
80         BSP_GYRO_GetXYZ(gyro_data);
81         BSP_MAGNETO_GetXYZ(maget_data_i16);
82
83         //gyro data
84         gyro_data[0]=(float)gyro_data_i16[0]/1000.0f;
85         gyro_data[1]=(float)gyro_data_i16[1]/1000.0f;
86         gyro_data[2]=(float)gyro_data_i16[2]/1000.0f;
87         gyro_magnitude=(float)sqrt(gyro_data[0]*gyro_data[0]+gyro_data[1]*gyro_data[1]+gyro_data[2]*gyro_data[2]);
88         //accel data
89         accel_data[0] = (float)accel_data_i16[0] / 100.0f;
90         accel_data[1] = (float)accel_data_i16[1] / 100.0f;
91         accel_data[2] = (float)accel_data_i16[2] / 100.0f;
92         //maget data
93         maget_data[0] = (float)maget_data_i16[0]/1000.0f;
94         maget_data[1] = (float)maget_data_i16[1]/1000.0f;
95         maget_data[2] = (float)maget_data_i16[2]/1000.0f;
96
97         if(firstdetect==0)
98         {
99             original_orientation[0]=maget_data[0];
100             original_orientation[1]=maget_data[1];
101             original_orientation[2]=maget_data[2];
102             firstdetect=1;
103         }
104         temp_data = BSP_TSENSOR_ReadTemp(); // read temperature sensor
105         humidity_data=BSP_HSENSOR_ReadHumidity(); // humid
106         pressure_data=BSP_PSENSOR_ReadPressure(); // pressure
107
108         sample_time=HAL_GetTick();
109     }

```

- Line 109- Line 142: First part of Healthy mode.

Mode toggle: press_time will record the last time of pressing the pushbutton. If the current time of pressing (HAL_GetTick) minus press_time is smaller than 1000 (1s), mode will be changed to 1 (Intensive Care mode), and all flags will be initialed. Otherwise, press_time will be updated to the current time of pressing the pushbutton.

enter1: Making sure the "Entering Healthy Mode" will only be printed once.

```

109     if(mode==0)
110     {
111         if(enter1==0)
112         {
113             HAL_UART_Transmit(&huart1, (uint8_t*)healthymode, strlen(healthymode),0xFFFF);
114             enter1=1;
115         }
116         //mode toggle
117         if(buttonpress==1&&press==0)
118         {
119             press_time=HAL_GetTick();
120             press=1;
121             buttonpress=0;
122         }
123         else if(buttonpress==1&&press==1)
124         {
125             if(HAL_GetTick()-press_time<1000)
126             {
127                 mode=1;
128                 press=0;
129                 buttonpress=0;
130                 enter2=0;
131                 blink=0;
132                 temp_warning=0;
133                 fall_warning=0;
134                 gyro_warning=0;
135                 magnet_warning=0;
136                 humid_warning=0;
137                 pressure_warning=0;
138             }
139             else {
140                 press_time=HAL_GetTick();
141                 buttonpress=0;}
142         }

```

- Line 143- Line 163: Second part of Healthy mode

If the body temperature is abnormal or free fall is detected, the LED flag will be updated (LED blinks in 2Hz), and warning messages will be printed every 10 seconds by checking the difference between the current time (HAL_GetTick) and current_time (the time of last print).

```

143     //temperature&&free_fall
144     if(HAL_GetTick()-current_time>10000)
145     {
146         if(temp_data>TEMP_THRESHOLD)
147         {
148             temp_warning=1;
149         }
150         if(temp_warning==1)
151         {
152             HAL_UART_Transmit(&huart1, (uint8_t*)fever, strlen(fever),0xFFFF);
153             blink=1;
154         }
155         if(fall_warning==1)
156         {
157             HAL_UART_Transmit(&huart1, (uint8_t*)fall, strlen(fall),0xFFFF);
158             blink=1;
159         }
160         current_time=HAL_GetTick();
161     }
162
163

```

- Line 167- Line 188: First part of Intensive Care mode

enter2: Making sure “Entering Intensive Care Mode” will only be printed once.

Mode toggle: If the pushbutton is pressed, all flags will be initialed to 0, and LED will be reseted.

```

167     if(mode==1)
168     {
169         if(enter2==0)
170         {
171             HAL_UART_Transmit(&huart1, (uint8_t*)intensivemode, strlen(intensivemode),0xFFFF);
172             enter2=1;
173         }
174         //mode toggle
175         if(buttonpress==1)
176         {
177             mode=0;
178             buttonpress=0;
179             enter1=0;
180             blink=0;
181             temp_warning=0;
182             fall_warning=0;
183             gyro_warning=0;
184             magnet_warning=0;
185             humid_warning=0;
186             pressure_warning=0;
187             HAL_GPIO_WritePin(GPIOB, LED2_Pin, GPIO_PIN_RESET);
188         }

```

- Line 190- Line 232: Second part of Intensive Care mode

If any of the sensor data is beyond the safety threshold, the system will update the warning flags. Subsequently, the system will print warning message on computer every 10 seconds by checking the difference between the current time (HAL_GetTick) and current_time (the time of last print).

```

190 //warning message
191 if(HAL_GetTick()-current_time>10000)
192 {
193     /*temp sensor*/
194     if(temp_data>TEMP_THRESHOLD)
195         temp_warning=1;
196     if(temp_warning==1)
197     {
198         HAL_UART_Transmit(&huart1, (uint8_t*)fever, strlen(fever),0xFFFF);
199         blink=1;
200     }
201     /*accel sensor*/
202     if(fall_warning==1)
203     {
204         HAL_UART_Transmit(&huart1, (uint8_t*)fall, strlen(fall),0xFFFF);
205         blink=1;
206     }
207     /*gyro sensor*/
208     if(gyro_magnitude>GYRO_THRESHOLD)
209     {
210         gyro_warning=1;
211     }
212     if(gyro_warning==1)
213     {
214         HAL_UART_Transmit(&huart1, (uint8_t*)pain, strlen(pain),0xFFFF);
215         blink=1;
216     }
217     /*humidity and pressure sensor*/
218     if(humidity_data<HUMID_THRESHOLD)
219     {
220         humid_warning=1;
221     }
222     if(pressure_data>PRESSURE_THRESHOLD)
223     {
224         pressure_warning=1;
225     }
226
227     if(humid_warning==1||pressure_warning==1)
228     {
229         HAL_UART_Transmit(&huart1,(uint8_t*)breath,strlen(breath),0xFFFF);
230         blink=1;
231     }
232

```

- Line 233- Line 246: Third part of Intensive Care mode

The system will always print all kinds of data on computer every 10 seconds by checking the difference between the current time (HAL_GetTick) and current_time (the time of last warning-printing, also the time of last data-printing).

memset: Reset the line_print to reuse this string.

```

233 sprintf(line_print,"%3d_TEMP_%2f_ACC_%2f_%2f_%2f \r\n",seconds_count,temp_data,accel_data[0]/9.8, accel_data[1]/9.8, accel_data[2]/9.8);
234 HAL_UART_Transmit(&huart1,(uint8_t*)line_print , strlen(line_print),0xFFFF);
235 seconds_count++;
236 memset(line_print,0,strlen(line_print));
237 sprintf(line_print,"%3d_GYRO_%1f_MAGNETO_%1f_%1f_%1f \r\n",seconds_count,gyro_magnitude,magnet_data[0], magnet_data[1], magnet_data[2]);
238 HAL_UART_Transmit(&huart1,(uint8_t*)line_print,strlen(line_print),0xFFFF);
239 seconds_count++;
240 memset(line_print,0,strlen(line_print));
241 sprintf(line_print,"%3d HUMIDITY_%1f and BARO_%2f \r\n",seconds_count,humidity_data,pressure_data);
242 HAL_UART_Transmit(&huart1,(uint8_t*)line_print,strlen(line_print),0xFFFF);
243 seconds_count++;
244 memset(line_print,0,strlen(line_print));
245
246 current_time=HAL_GetTick();

```

- Line 248- Line 269: Fourth part of Intensive Care mode

If the system finds the patient's body orientation is changed (magnet_warning is updated), it will then print "Check patient's abnormal orientation!" on the computer immediately by checking the difference between the current time (HAL_GetTick) and lying_time (the time of last print of magnet_warning).


```

248         if(HAL_GetTick()-lying_time>10000)
249         {
250             if((maget_data[0]-original_orientation[0])>0.3||((original_orientation[0]-maget_data[0])>0.3)
251             {
252                 magnet_warning=1;
253             }
254             if((maget_data[1]-original_orientation[1])>0.3||((original_orientation[1]-maget_data[1])>0.3)
255             {
256                 magnet_warning=1;
257             }
258             if((maget_data[2]-original_orientation[2])>0.3||((original_orientation[2]-maget_data[2])>0.3)
259             {
260                 magnet_warning=1;
261             }
262             if(magnet_warning==1)
263             {
264                 HAL_UART_Transmit(&huart1, (uint8_t*)orientation, strlen(orientation),0xFFFF);
265                 blink=1;
266             }
267             lying_time=HAL_GetTick();
268         }
269     }

```

- Line 270- Line 328: Enhancement: Password Page and Welcome Page
- Line 329- Line 338:

If the flag for LED blinking (blink) is 1, the LED will blink in 2Hz by checking the difference between the current time (HAL_GetTick) and blink_time (the time of last TogglePin, or the time of last blinking).

```

329         if(blink==1)
330         {
331             if(HAL_GetTick()-blink_time>500)
332             {
333                 HAL_GPIO_TogglePin(GPIOB,GPIO_PIN_14);
334                 blink_time=HAL_GetTick();
335             }
336         }
337     }
338 }

```

- Line 342- Line 407:
- UART, peripherals GPIO configuration.

```

342 static void MX_GPIO_Init(void)
343 {
344     GPIO_InitTypeDef GPIO_InitStruct = {0};
345     /* GPIO Ports Clock Enable */
346     __HAL_RCC_GPIOB_CLK_ENABLE();
347     __HAL_RCC_GPIOC_CLK_ENABLE();
348     __HAL_RCC_GPIOH_CLK_ENABLE();
349     /*Configure GPIO pin Output Level */
350     //pushbutton
351     HAL_GPIO_WritePin(GPIOC,BUTTON_EXTI13_Pin, GPIO_PIN_RESET);
352     GPIO_InitStruct.Pin = BUTTON_EXTI13_Pin;
353     GPIO_InitStruct.Mode = GPIO_MODE_IT_FALLING;
354     GPIO_InitStruct.Pull = GPIO_PULLUP;
355     HAL_GPIO_Init(GPIOC, &GPIO_InitStruct);
356     //freefall
357     HAL_GPIO_WritePin(GPIOH,LSM6DSL_INT1_EXTI11_Pin, GPIO_PIN_RESET);
358     GPIO_InitStruct.Pin = LSM6DSL_INT1_EXTI11_Pin;
359     GPIO_InitStruct.Mode = GPIO_MODE_IT_FALLING;
360     GPIO_InitStruct.Pull = GPIO_PULLUP;
361     HAL_GPIO_Init(GPIOH, &GPIO_InitStruct);
362     //led
363     HAL_GPIO_WritePin(GPIOB, LED2_Pin, GPIO_PIN_RESET);
364     GPIO_InitStruct.Pin = LED2_Pin;
365     GPIO_InitStruct.Mode = GPIO_MODE_OUTPUT_PP;
366     GPIO_InitStruct.Pull = GPIO_NOPULL;
367     GPIO_InitStruct.Speed = GPIO_SPEED_FREQ_LOW;
368     HAL_GPIO_Init(GPIOB, &GPIO_InitStruct);
369 }
370

```

```

371 static void UART1_Init(void)
372 {
373     /* Pin configuration for UART. BSP_COM_Init() can do this automatically */
374     __HAL_RCC_GPIOB_CLK_ENABLE();
375     GPIO_InitTypeDef GPIO_InitStruct = {0};
376     GPIO_InitStruct.Alternate = GPIO_AF7_USART1;
377     GPIO_InitStruct.Pin = GPIO_PIN_7[GPIO_PIN_6;
378     GPIO_InitStruct.Mode = GPIO_MODE_AF_PP;
379     GPIO_InitStruct.Pull = GPIO_NOPULL;
380     GPIO_InitStruct.Speed = GPIO_SPEED_FREQ_VERY_HIGH;
381     HAL_GPIO_Init(GPIOB, &GPIO_InitStruct);
382
383     /* Configuring UART1 */
384     huart1.Instance = USART1;
385     huart1.Init.BaudRate = 115200;
386     huart1.Init.WordLength = UART_WORDLENGTH_8B;
387     huart1.Init.StopBits = UART_STOPBITS_1;
388     huart1.Init.Parity = UART_PARITY_NONE;
389     huart1.Init.Mode = UART_MODE_TX_RX;
390     huart1.Init.HwFlowCtl = UART_HWCONTROL_NONE;
391     huart1.Init.OverSampling = UART_OVERSAMPLING_16;
392     huart1.Init.OneBitSampling = UART_ONE_BIT_SAMPLE_DISABLE;
393     huart1.AdvancedInit.AdvFeatureInit = UART_ADVFEATURE_NO_INIT;
394     if (HAL_UART_Init(&huart1) != HAL_OK)
395     {
396         while(1);
397     }
398 }
399 _

```

```


400 void HAL_GPIO_EXTI_Callback(uint16_t GPIO_Pin)
401 {
402     if(GPIO_Pin==GPIO_PIN_13)//mode_toggle
403         buttonpress=1;
404     if(GPIO_Pin==GPIO_PIN_11)//Free fall
405         fall_warning=1;
406 }
407

```

5. Enhancement

This enhancement consists of two parts, including Welcome Page, and Password Page. The Welcome Page requires user to type in “START” to start the whole system. This function can prevent users from mistouch. After typing “START”, the system will then switch to Password Page. Users are required to type in the correct password (0000) to start the Healthy Mode. Otherwise, this system will not be switched. Also, users could type in “EXIT” or “Exit” or “exit” to exit from password page and enter welcome page. This function can ensure the system not be used by other unauthorized users.

- Enhancement demonstration:
 - Welcome Page



- Password Page

```

COM4 - Tera Term VT
File Edit Setup Control Window Help
This is a system to enhance monitoring of COVID patients
Please enter START to continue
START
System Starting....
Please enter 4-digit password

```

C. Wrong password

```

Please enter 4-digit password
1111
Password incorrect.<Enter EXIT to quit>
Please enter 4-digit password

```

D. Correct password

```

Please enter 4-digit password
0000
Entering Healthy Mode

```

E. Exit from password Page

```

Please enter 4-digit password
EXIT
Exit Successfully
This is a system to enhance monitoring of COVID patients
Please enter START to continue

```

- Enhancement code

- A. Line 270- Line 301: The system will verify the correctness of the entered password. The system will compare the string user typed in with "0000", "EXIT", "Exit", and "exit" to determine the system's next mode.

mode=3: Password Page

memset: clear the content of buffer to reuse this variable.

"\r": move cursor to the first letter of this line

"\n": move cursor to next line

buffer: the string user typed in

```

270     if(mode==3)
271     {
272         char enterpassword[]="Please enter 4-digit password\n\n";
273         HAL_UART_Transmit(&huart1, (uint8_t*)enterpassword, strlen(enterpassword),0xFFFF);
274         memset(buffer,0,strlen(buffer));
275         len=0;
276         do
277         {
278             HAL_UART_Receive(&huart1, (uint8_t*)&data,1,0xFFFF);
279             if(data!='\r' && data!='\n')
280             {
281                 len++;
282                 buffer[len-1]=data;
283             }
284         }
285         while((len<=64)&&(data!='\r'));
286         buffer[len]='\0';
287
288         if(strcmp(exitmode1,buffer)==0||strcmp(exitmode2,buffer)==0||strcmp(exitmode3,buffer)==0)
289         {
290
291             mode=4;
292             HAL_UART_Transmit(&huart1, (uint8_t*)exitmode, strlen(exitmode),0xFFFF);
293         }
294         else
295         { if(strcmp(password,buffer)==0)
296           (mode=0;}
297           else
298             HAL_UART_Transmit(&huart1, (uint8_t*)wrong, strlen(wrong),0xFFFF);
299         }
300     }
301 }

```

- B. Line 305- Line 328: Users should type “START” to start the monitoring system. The system will compare the string user typed in with “START” to determine the system’s next mode.

mode=4: Welcome Page

```

305     if(mode==4)
306     {
307         char mode_start[]="This is a system to enhance monitoring of COVID patients\n\nPlease enter START to continue\n\n";
308         char start[]="System Starting...\n\n";
309         HAL_UART_Transmit(&huart1, (uint8_t*)mode_start, strlen(mode_start),0xFFFF);
310         memset(buffer,0,strlen(buffer));
311         len=0;
312         do
313         {
314             HAL_UART_Receive(&huart1, (uint8_t*)&data,1,0xFFFF);
315             if(data!='\r' && data!='\n')
316             {
317                 len++;
318                 buffer[len-1]=data;
319             }
320         }
321         while((len<=64)&&(data!='\r'));
322         buffer[len]='\0';
323         if(strcmp("START",buffer)==0)
324         {
325             HAL_UART_Transmit(&huart1, (uint8_t*)start, strlen(start),0xFFFF);
326             mode=3;
327         }
328     }

```

6. Problems and solutions

We encountered three major problems in this assignment.

- Problem1: How can we decide the switch of the mode by checking the button is pressed twice within 1 second?

Solution1: Use press_time to record the first time the button is pressed. Check the difference of the two pressing times. If the difference of two pressing time is within 1000 (1s), mode switched. If the difference time is beyond 1000, the press_time will be updated to second time of button-pressing. And the system waits for another button press. In other words, press_time will record the last time of button press. And system will check the difference between the current press time and last press time (press_time).
- Problem2: Entering difference strings needs numerous arrays to read them. How to simplify this process?

Solution2: memset function. This function can clear the array, so that we can reuse one array for several times.
- Problem3: Printing “Please enter 4-digit password” will also include “\r” and “\n” to place

the cursor to the beginning of the next line. However, “\r” and “\n” will also be recorded in the reading array (it is called “data” in our code), which will affect the strcmp function. How can we get rid of it?

Solution3: Judgement statement. If the element in the reading array (“data”) is “\r” or “\n”, the code will skip this element. Except “\r” and “\n”, other elements will be transferred to another new array (it is called “buffer” in our code). Subsequently, the new array (“buffer”) will participate in strcmp function.

7. Issue and suggestions

This project is suggested to do further improvement on Internet connectivity. Future designers may work more on Wi-Fi connection and database establishment. COPEMON could be further developed as a node to a bigger IoT monitoring system. In addition, shared database of this IoT monitoring system is also preferred. Medical practitioners could acquire, analyze, and summarize patient’s body situation characteristics from this database.

8. Conclusion

In this assignment, in order to monitor COVID patients’ health situation, we finished to design a preliminary two-mode monitoring system called COPEMON by using STM32. Health data detection, analysis, and printing are achieved by implementing different kinds of interfacing with embedded system. Hope everyone takes great care in this pandemic era, and none of my beloved professors, tutors, and friends use my COPEMON.